


**CABLE SET:**

P/N	QTY	DESCRIPTION
TS-2018	1	Output cable from spreader to hydraulic valve
TS-2004	1	Ground speed input and remote blast/pass
MK-1003	1	Main Power and Ground
TS-2020	1 - 4	Hydraulic Pigtail from TS-2018 to hydraulic valve solenoid
***Options for the pigtails pending the termination on the hydraulic coil***		
TS-1000	1	Sensor main trunk - no bulkhead disconnect
	or	
TS-8000	1	Sensor main trunk - bulkhead mount (requires TS-8001)
	and	
TS-8001	1	Sensor junction block bulkhead connector (connects to TS-8000)
TS-2005	1 - 4	Sensor Pigtail from TS-1000 to sensors on Auger/Spinner/Prewet/Anti-Ice
***Options for the pigtails pending the termination on the implement sensor***		



ENTIRE DOCUMENT IS FOR REFERENCE ONLY

THIS DRAWING IS THE PROPERTY OF CIRUS CONTROLS. THIS IS TO BE CONSIDERED CONFIDENTIAL AND PROPRIETARY. NO REPRODUCTION IN WHOLE OR PART WITH OUT PERMISSION IS ALLOWED.

**CIRUS CONTROLS LLC**  
 Phone: (763) 493-9380  
 Fax: (763) 493-9340  
 7165 BOONE AVE. N. SUITE 190  
 BROOKLYN PARK, MN 55428

REV	DATE	DESCRIPTION	INSTALLATION GUIDE			
A	-	-	Dual Spread			
B	-	-				
C	-	-				
D	-	-				
E	-	-				
DESIGN:	DRAWN:	AS BUILT:	PROJECT NUMBER:	SCALE:	DATE:	REV.
-	KTM	-	-	NONE	01/05/11	-
					SHT 1 OF 1	